





## UART I/O Signals

The I/O signals for the UART are listed in [Table 2](#). The interfaces referenced in this table are shown in [Figure 1](#) in the UART block diagram.

*Table 2: UART I/O Signals*

Grouping	Signal Name	Interface	I/O	Description	
PLB Slave Signals	P1	PLB_abort	PLB	I	PLB abort bus request indicator
	P2	PLB_ABus(0:C_PLB_AWIDTH-1)	PLB	I	PLB address bus
	P3	PLB_BE(0:(C_PLD_DWIDTH / 8) -1)	PLB	I	PLB byte enables
	P4	PLB_busLock	PLB	I	PLB bus lock
	P5	PLB_compress	PLB	I	PLB compressed data transfer indicator
	P6	PLB_guarded	PLB	I	PLB guarded transfer indicator
	P7	PLB_lockErr	PLB	I	PLB lock error indicator
	P8	PLB_masterID(0:C_PLB_MID_WIDTH-1)	PLB	I	PLB current master indicator
	P9	PLB_ordered	PLB	I	PLB synchronize transfer indicator
	P10	PLB_PAValid	PLB	I	PLB primary address valid indicator
	P11	PLB_rdBurst	PLB	I	PLB burst read transfer indicator
	P12	PLB_rdPrim	PLB	I	PLB secondary to primary read request indicator
	P13	PLB_RNW	PLB	I	PLB read not write
	P14	PLB_SAValid	PLB	I	PLB secondary address valid indicator
	P15	PLB_size(0:3)	PLB	I	PLB transfer size
	P16	PLB_type(0:2)	PLB	I	PLB transfer type
	P17	PLB_wrBurst	PLB	I	PLB burst write transfer indicator
	P18	PLB_wrDBus(0:C_PLB_DWIDTH -1)	PLB	I	PLB write data bus
	P19	PLB_wrPrim	PLB	I	PLB secondary to primary write request indicator
	P20	PLB_MSize(0:1)	PLB	I	PLB master data bus size
	P21	PLB_pendReq	PLB	I	PLB pending bus request indicator
	P22	PLB_pendPri(0:1)	PLB	I	PLB pending request priority
	P23	PLB_reqPri(0:1)	PLB	I	PLB current request priority
	P24	SI_addrAck	PLB	O	Slave address acknowledge
	P25	SI_MBusy(0:C_NUM_MASTERS-1)	PLB	O	Slave busy indicator
	P26	SI_MErr(0:C_NUM_MASTERS-1)	PLB	O	Slave error indicator

























